



317.916.8000 • www.augustmack.com
1302 North Meridian Street, Suite 300 • Indianapolis, Indiana 46202

May 7, 2024

Mr. Brad Davison
Iowa Department of Natural Resources
Land Quality Bureau
Land Recycling Program
502 E 9th Street
Des Moines, Iowa 50319

**RE: Response to Risk Evaluation & Response Action (RE/RA) Comments
Union at Rivers Edge
1600 Indianola Avenue
Des Moines, Iowa
Land Recycling Program ID 1514
August Mack Project Number JX0352.380**

Dear Mr. Davison:

On behalf of Union at Rivers Edge, LP (The Annex Group), August Mack Environmental, Inc. (August Mack) is submitting this *Response to Risk Evaluation & Response Action (RE/RA) Comments* for the above-referenced facility (Site). August Mack submitted a *RE/RA Plan* to Iowa Department of Natural Resources (IDNR) on November 16, 2023, which was discussed with IDNR in a January 10, 2024 meeting and officially responded to in their April 15, 2024 Land Recycling Program (LRP) RE/RA comment letter. This *Response to RE/RA Comment* letter was prepared in response to the IDNR April 15, 2024 comment on concrete not being an adequate cap to prevent exposure to surface soils. Specifically, this letter addresses the following IDNR comment:

DNR agrees that a clean soil cap is an effective option to eliminate the exposure pathways to contaminated soil. However, the cap described in the RE/RA is inadequate and should be expanded to encompass the entire property. DNR does not recognize concrete, asphalt, or vegetation as an adequate capping material at a residential site unless paired with a clean soil cap. These materials are subject to deterioration which could possibly complete an exposure pathway. An exception can be made in regards to the concrete foundations of any building constructed on site, and are not required to be constructed on a clean soil cap.

The reasoning for extending the cap is that primary risk associated with residential use is children's exposure to contaminated surface soils. The LRP conservatively specifies surface soil to be the top two feet of soil. If the contaminated soil (i.e. above residential standards)



remains below the two feet of fill and continues to be properly managed, this exposure pathway is eliminated.

This general comment was discussed during the January 10, 2024 meeting with IDNR, who clarified in an February 19, 2024 email that the clean cap could include “a cumulative of two feet of clean material. So, if there is 1.5 feet of clean soil and 0.5 feet of asphalt that would be enough as an example.” August Mack responded to IDNR’s email on February 19, 2024 asking for clarification on the specific regulation that states concrete is not an adequate cap to prevent exposure to contaminated soils. IDNR responded in a March 14, 2024 email stating the following:

“This is not a regulation. Rather, it is a Departmental decision made by our Legal section ...that set precedent for the Land Recycling Program (LRP) regarding residential reuse. Additionally, this helps us meet the objectives of the (LRP) which are to reduce current and future risks associated with contaminated property (137.1(2)) and eliminate exposure pathways of the remaining contamination.”

The precedent document provided was not a legal ruling, but rather a comment letter drafted by an IDNR attorney and issued to Pittsburg De Moines Steel in December 2009. Although the full scope of the remedial design at the Pittsburg De Moines Steel site was not outlined in the comment letter, there was no reference to paved asphalt/concrete caps throughout the document; therefore, it is unclear how the precedent applies to the Site since concrete will be placed at the surface.

Based on the precedent uncertainty and the fact that there are no IDNR regulations stating concrete is an inadequate cap, August Mack offers the four following responses regarding the request for a cumulative two-foot clean fill cap to prevent exposure to the contaminated soil at the Site:

1. Concrete is an adequate capping material to eliminate any potential soil exposure.
2. Although concrete will degrade over time, an Environmental Covenant (EC) will be recorded to confirm that the concrete degradation is managed appropriately to prevent a complete exposure pathway.
3. Although there are Range 1 surface soils (0-2 feet) that exceeded IDNR’s Statewide Soil Standards, the reported concentration of constituents in surface soils does not present a risk to human health or the environment to require the need for any cap.
4. Although there is currently an unacceptable risk identified in Range 2 soils (deeper than 2-feet), the elevated lead concentration at SB-106 will be removed during redevelopment, and based on the updated EPC, the Range 2 soils will not present a risk to human health or the environment.

These four responses and the supporting lines of evidence (LOE) are discussed in more detail below.

1. Concrete is an adequate capping material to eliminate any potential soil exposure based on the following LOE:
 - a. The United States Environmental Protection Agency (US EPA) Engineering Controls on Brownfields Information Guide (provided in **Attachment A**) specifically gives an example where, “elements of the redevelopment (e.g., paving, building foundations) can serve as the engineering controls by providing barriers to eliminate potential exposures to soil, groundwater, and other environmental media.”
 - b. This US EPA example uses concrete as a cap to “prevent contact with the contaminated soil,” which is exactly how the Union at Rivers Edge redevelopment was designed.
 - c. Concrete is far less susceptible to erosion and degradation than the IDNR accepted two feet of clean soil cap, making it a more protective and durable barrier than a standalone 2-foot clean soil cap.
2. Although concrete will degrade over time, an Environmental Covenant (EC) will be recorded to confirm that the concrete degradation is managed appropriately to prevent a complete exposure pathway based on the following LOE:
 - a. An EC will be recorded on the property requirements for the adherence to an IDNR approved Soil Management Plan (SMP) and Operations, Maintenance, and Monitoring (OM&M) plan.
 - b. The OM&M plan will require continued monitoring and maintenance of all materials overlying contaminated soils (clean soil and concrete).
 - c. As part of the OM&M plan, all observed deterioration (cracks, ruts, channels, etc.) shall be repaired or restored in a manner that maintains the effectiveness of the capping material to prevent exposure to underlying contaminated soils.
 - d. Prior to installation of capping materials, a visual demarcation fabric will be installed over contaminated soils not covered by Site structures. The OM&M plan will require any areas with observable fabric deterioration be isolated and the cap material be repaired or replaced immediately.
3. Although there are Range 1 surface soils (0-2 feet) that exceeded IDNR’s Statewide Soil Standards, the reported concentration of constituents in surface soils do not present a risk to human health or the environment to require the need for any cap based on the following LOE:
 - a. The primary constituent of concern reported in shallow soils above IDNR Statewide Standards for Soil was arsenic, which is naturally occurring and ubiquitous throughout the state.
 - b. Reported arsenic concentration in Range 1 soils were only slightly above the calculated background threshold values (BTVs) for the Site.
 - c. Risk evaluation results based on calculated exposure point concentrations (EPCs) and the IDNR cumulative risk calculator, which were provided in

the *RE/RA Plan*, did not identify an unacceptable risk to future residents and Range 1 soils.

4. Although there is currently an unacceptable risk identified in Range 2 soils (deeper than 2-feet), the elevated lead concentration at SB-106 will be removed during redevelopment, and based on the updated EPC, the Range 2 soils will not present a risk to human health or the environment.
 - a. The unacceptable risk identified in Range 2 soils (deeper than 2-feet) was due to the elevated lead concentration of 808 mg/kg in at SB-106 from 2 - 4 feet below grade.
 - b. The proposed redevelopment activities at the property include the installation of an underground detention area, which is depicted in **Attachment B** and involves the removal of soils from the vicinity of SB-106 to 5-feet below grade.
 - c. Based on the updated EPC with the elevated lead concentration (808 mg/kg) at SB-106 being removed (provided in **Attachment C**), the revised EPC resultant of 181 mg/kg is less than the applicable Iowa Statewide Standard, as well as below the January 2024 U.S. EPA updated recommended residential lead Regional Screening Level of 200 mg/kg; therefore, the Range 2 soils will not present a risk to human health or the environment.


Based on the LOE presented above, the proposed concrete cap associated with building foundations, sidewalks, and parking lots in conjunction with the proposed EC will effectively eliminate potential exposures to underlying contaminated soils and prevent any potential risk to human health or the environment. As such, a clean soil cap is only warranted in the greenspace on-Site as proposed in the *RE/RA Plan*.

August Mack trusts that this document meets your approval. Please feel free to contact us should you have any questions or comments regarding this submittal.

Sincerely,



Steven Faulk
Project Manager



Charlie Gomez, LPG
Principal of Closure

Attachment A

US EPA Engineering Controls on Brownfields Information Guide

Engineering Controls on Brownfields Information Guide:

How They Work with Institutional Controls; the Most Common Types Used; and an Introduction to Costs

Introduction

Engineering controls (ECs) encompass a variety of engineered and constructed physical barriers (e.g., soil capping, sub-surface venting systems, mitigation barriers, fences) to contain and/or prevent exposure to contamination on a property. In contrast, institutional controls (ICs) are administrative or legal instruments (e.g., deed restrictions/notices, easements, covenants, zoning) that impose restrictions on the use of contaminated property or resources. ICs are also used to identify the presence of ECs and long-term stewardship (LTS) requirements. Long-term stewardship refers to the activities necessary to ensure that ECs are maintained and that ICs continue in force. Additional information regarding LTS can be found at: www.epa.gov/brownfields/tools/lts_fs_04_2008.pdf

The need for ECs and/or ICs is identified as part of selecting a cleanup remedy and will vary depending on a number of factors, including but not limited to, the planned activity and land use for the property, the extent and location of contamination, and the environmental medium impacted. While it is not uncommon to find ICs without ECs, ICs are typically an integral part of EC protectiveness. For example, the most common ICs for brownfield cleanup projects (e.g., deed notices/restrictions, environmental covenants, state registries) provide information or notifications that residual contamination may remain on a property and identify ECs such as caps, mitigation barriers, or fencing, which are intended to restrict access and exposure to contamination, and eliminate further migration of contamination. Over the past several years environmental covenants have become an increasingly popular form of LTS to address activity and land use restrictions and engineering control installation, operation, and maintenance. Environmental covenants provide a mechanism to ensure that land use restrictions, mandated environmental monitoring requirements, and a wide range of common engineering controls designed to control the potential environmental risk of residual contamination will be reflected on the land records and effectively enforced over time as valid real property servitude. Currently 25 states have enacted legislation to adopt a form of the Uniform Environmental Covenants Act (UECA). More information regarding UECA can be found at: www.environmentalcovenants.org/

There are many different types of ECs and they vary from property to property, depending on the contaminants found and the type of media impacted. The following is a list of the more commonly used ECs at brownfield properties.

- **Capping in Place (Asphalt or Concrete)** – The use of paved areas (e.g., parking lots, roadways) and building foundations as surface barriers or caps over contaminated soil. Capping in place involves creating and maintaining a hard surface, usually concrete or asphalt, over contamination. The result is a high strength, low permeability cover that reduces surface water infiltration and stabilizes contaminated soils. As a result, the cap prevents contact with the contaminated soil and contaminant mobility is limited protecting ground water.
- **Capping in Place (Clean Fill)** – Placement of defined thickness of clean fill over an area of contaminated soil (e.g., 2-3 feet of soil for non-residential uses, 10 feet for residential uses) to prevent contact with the contaminated soil.



*Paved areas such as parking lots and roadways
can be used as caps over contaminated soil*

- **Passive Depressurization Systems** – Installation of a passive vapor control system in conjunction with a vapor barrier under buildings to minimize potential migration of volatile contamination to indoor air. A passive depressurization system relies on a natural convection of air to draw air from the soil beneath a building and discharges it to the atmosphere through a series of collection and discharge pipes.
- **Active Depressurization Systems** – Installation of an active vapor control system in conjunction with a vapor barrier under buildings to minimize potential migration of volatile contamination to indoor air. An active depressurization system consists of a fan or blower which draws air from the soil beneath a building and discharges it to the atmosphere through a series of collection and discharge pipes.
- **Ground Water Migration Barriers** (e.g., barrier wall, ground water depression systems) – The use of a vertical impermeable barrier to limit exposure by cutting off the route and preventing migration of contaminated ground water or leachate from a contaminated property.

Engineering Controls Integrated Into Redevelopment

An important consideration for ECs in the context of brownfields redevelopment is the benefit of integrating the implementation and long-term stewardship of the ECs into the redevelopment of a property. In some cases, elements of the redevelopment (e.g., paving, building foundations) can serve as the EC by providing barriers to eliminate potential exposures to soil, ground water, and other environmental media. In cases where ECs are an integral part of the redevelopment, however, it may be difficult to separate the specific cost of the EC from the redevelopment. For example, where a parking lot is used as a cap over contaminated soil, the cost of site preparation and paving would have already been a consideration for the cost of the redevelopment. The cost of the EC would be any incremental costs that would not have been incurred during the paving if the contaminants were not present in the soil.

Although these five ECs are the most commonly used on brownfield redevelopment projects, other types of ECs are also used to reduce exposure to and migration of contamination left on the property. Other ECs used on brownfield properties include, but are not limited to:

- **Security Barriers and Fencing** – Used to restrict access to contaminated and unsafe brownfield properties.
- **Solidification/Stabilization** – Occurs by injecting or mixing cement into contaminated soil to lock contaminants into a structurally sound mass of solid material for disposal.
- **Geotextile Fabric Barriers** – Separate, filter, drain, or reinforce soils.
- **Engineered Caps** – Designed to meet specific performance and containment requirements such as permeability.
- **Leachate Collection Systems** – Direct and collect contaminated leachate, and then transport it offsite for disposal.
- **Permeable Reactive Barriers** – Walls that are built below ground and are composed of materials that remove contaminants from ground water as it flows through the permeable barrier.

In addition, remedial actions such as ground water pump and treat systems, soil vapor extraction systems, and monitored natural attenuation may continue beyond the change in use or redevelopment of a property. In these cases, long-term stewardship similar to engineering controls will be required and can be incorporated into institutional controls such as environmental covenants.

Engineering Control Use at Brownfield Properties

Each brownfield property redevelopment project is different and the need for ECs and/or ICs is based on several factors during the selection of the cleanup strategy. Property specific factors influence the selection of the cleanup remedy and control measures. A list of typical brownfield properties, the general types of contamination found at those properties, and the most common ECs follows.

- Gasoline service stations and auto body repair shops are typically contaminated with petroleum hydrocarbons from underground storage tanks (USTs) and, in some cases, metals associated with motor and hydraulic oils and cleaning solvents. These properties generally use land use and resource restrictions (ICs) along with capping technologies and active/passive depressurization systems to address residual contamination left on the property.
- Industrial properties are typically contaminated with asbestos, heavy metals, volatile organic compounds (VOCs), semi-volatile organic compounds (SVOC), and polychlorinated biphenyls (PCBs) from manufacturing operations at the property. These properties generally use land use restrictions (ICs) along with capping technologies, active/passive depressurization systems, and security barriers (e.g., fences) to mitigate exposure to contamination left on the property.
- Commercial properties (e.g., dry cleaning operations) are typically contaminated with asbestos, VOCs, polycyclic aromatic hydrocarbons (PAHs), and PCBs from operations at the property. These properties generally use ICs (i.e., land use and resource restrictions) along with capping technologies (e.g., asphalt or clean fill) to address residual contamination left on the property.
- Landfills and dumps are typically contaminated with oils, paints, solvents, corrosive cleaners, batteries, VOCs, PAHs, and PCBs from the waste disposal at the property. These properties generally use ICs (i.e., land use and resource use restrictions) along with capping technologies and ground water mitigation barriers to reduce exposure and migration of contamination from the property.

Engineering Controls and Cleanup

ECs are typically considered a form of cleanup; however, it is important to recognize that there is a distinction between ECs and other forms of cleanup. ECs are often installed during cleanup as a condition of a no further action determination and are generally intended to be in place for long periods of time. In many cases, the presence and long-term stewardship (e.g., O&M) of ECs are defined in environmental covenants, O&M agreements, or other instruments. Other forms of cleanup may reduce or remove contamination in soil, ground water, and other environmental media (e.g., soil removal and disposal, ground water treatment, soil vapor extraction and treatment). These remedial actions are designed to be short term and targeted to meet a defined endpoint (e.g., corrective action goal or risk-based concentration in soil or ground water). While ECs are intended to be in place beyond the no further action determination, cleanups to reduce or remove contamination are typically completed before a no further action determination is made. It is important to note that in some cases, the technology implemented for ECs may be very similar to the technology implemented for reduction or cleanup. For example, a ground water pump and treat system can be used to reduce contamination in ground water or it can be used as an EC to control ground water migration.

Engineering Control Costs

The cost of installing and maintaining ECs is different for each property. In many cases, the costs of installing an EC is an integral part of a property redevelopment (e.g., paving as capping, or a building foundation as a cap) with little additional costs attributable to the EC. The range of costs to install and maintain ECs is, therefore, dependent upon several factors, including but not limited to: construction activities on the property; size of the property; extent and concentration of contamination; size of the building(s) or structure(s) on the property; location of the property; and depth to ground water.

There are three general types of costs associated with ECs: programmatic costs, capital costs, and operation and maintenance costs.

- Programmatic costs are incurred when municipal or local governments develop and implement LTS programs. Programmatic costs include: preliminary costs to develop the program, long-term planning for implementation, public outreach, and developing monitoring and enforcement plans.
- Capital costs are costs incurred for the design, construction, and installation of the EC. Capital costs may include, but are not limited to: mobilization and demobilization; monitoring, sampling, testing, and analysis; site work; design

Type of EC	Range of Capital Costs	Activities included in Capital Costs	Range of O&M Costs*	Activities included in O&M Costs
Capping in Place (Asphalt or Concrete)	<ul style="list-style-type: none"> Clearing: \$5,000 to \$7,500 per acre 1" Sub-base: \$2.50 to \$7.00 per square yard 1.5" Surface: \$12.00 to \$20.00 per square yard Swale: \$15.00 to \$25.00 per linear foot 	<ul style="list-style-type: none"> Site clearing Equipment mobilization Initial surface compaction Design and engineering Surface preparation Hard surface cap layer placement Edge drainage swale preparation CQA program 	<ul style="list-style-type: none"> \$1,000 annually 	<ul style="list-style-type: none"> Long-term inspections Repair of damages Site supervision Security Site quality assurance and health and safety
Capping in Place (Clean Fill)	<ul style="list-style-type: none"> Excavation: \$15 to \$30 per cubic yard Placement: \$50 to \$75 per cubic yard Surface preparation and Hydro-Seeding: \$100 to \$200 per 1,000 square feet 	<ul style="list-style-type: none"> Site clearing Equipment mobilization Initial surface compaction Design and engineering Surface preparation Cap layer placement Edge drainage swale preparation CQA program Irrigation system 	<ul style="list-style-type: none"> \$5,000 annually (vegetative cover) 	<ul style="list-style-type: none"> Long-term inspections Repair of damages Watering/irrigation system (to maintain vegetative cover) Mowing Utilities Site supervision Security Site quality assurance and health and safety
Passive Depressurization Systems	<ul style="list-style-type: none"> \$2,000 to \$5,000** 	<ul style="list-style-type: none"> Equipment mobilization Design and engineering Trenching and backfilling Vent piping Passive barrier installation Compaction and restoration GeoEngineer oversight 	<ul style="list-style-type: none"> \$1,000 to \$5,000 annually 	<ul style="list-style-type: none"> Long-term oversight and inspections Repair of damages Site supervision Site quality assurance and health and safety
Active Depressurization Systems	<ul style="list-style-type: none"> \$5,000 to \$20,000** 	<ul style="list-style-type: none"> Equipment mobilization Design and engineering Trenching and backfilling Vent piping Passive barrier installation Mobilize and install active system Compaction and restoration GeoEngineer oversight 	<ul style="list-style-type: none"> \$1,000 to \$10,000 annually 	<ul style="list-style-type: none"> Long-term oversight and inspections Performance and site Monitoring Utilities Repair of damages Site supervision Site quality assurance and health and safety
Ground Water Migration Barriers	<ul style="list-style-type: none"> Trench barrier: \$200 to \$1,000 per linear foot of trench*** Ground water depression: \$50,000 to \$500,000**** 	<ul style="list-style-type: none"> Equipment mobilization Design and engineering Migration wall construction and installation GeoEngineer oversight 	<ul style="list-style-type: none"> Trench barrier: \$3,000 to \$10,000 annually **** Ground water depression: \$5,000 to \$35,000 annually **** 	<ul style="list-style-type: none"> Long-term oversight and inspections Repair of damages Site supervision Site quality assurance and health and safety

* Assumes length of post-closure care is 20-30 years.

** Assumes average building size of 4,000 square feet.

*** The capital costs of ground water migration barriers are dependent on the type of barrier installed, the depth of the barrier and other site-specific conditions. The capital costs provide a range of costs considering the variability in these characteristics. Trenching assumes a maximum depth of 20 feet below the ground surface. Ground water depression assumes pumping rate of 1 to 10 gpm and that extracted water will be treated prior to discharge.

**** Assumes periodic ground water monitoring for trench barrier. Assumes periodic ground water monitoring and inspection and maintenance of pumping and treatment systems.

Note that the EC examples identified in the table do not include capital and operating costs associated with designing, installing, and operating a ground water monitoring program that may be required. Additional information regarding EC and IC costs can be found in An Introduction to the Cost of Engineering and Institutional Controls at Brownfield Properties at: www.epa.gov/brownfields/tools/lts_cost_fs.pdf

and engineering; construction and installation; off-site treatment and disposal; construction quality assurance (CQA); and project and construction management.

- **Operation & Maintenance (O&M) costs** associated with ECs should be considered throughout the lifecycle of property cleanup and post-cleanup care. O&M activities are conducted at a property after ECs are in place, to ensure that the action is effective and operating properly, and may include, but are not limited to: performance inspections and site monitoring; operating remediation systems, including sampling and analysis, preparing reports, and recordkeeping; maintaining caps and system maintenance; and site supervision.

The following table provides a range and list of costs for the more common ECs implemented on brownfield properties. The examples provided below only include site-specific capital and O&M costs incurred when designing, implementing, and monitoring ECs. The table does not include the programmatic cost to a municipality or local government to develop and implement a LTS program. In addition, each EC design and implementation will incur indirect and variable costs. These indirect and variable costs are not listed in the table and may include, but are not limited to: project management, vendor selection, permit preparation and fees, regulatory interaction, and contingencies.

Sources for Estimating Costs and Additional Resources

EC capital and O&M cost estimates can be generated from several sources. Cost-estimating software and databases can be used to calculate the capital and O&M costs of ECs. The majority of available software tools are designed to estimate the cost for all or selected cost elements of an EC. Below is a list of several sources for estimating costs of ECs.

- **Cost Estimating Guides/References** – Provide costs for a wide variety of construction activities, including those related to property cleanup. Some guides are specifically customized to estimate costs for environmental remediation projects. Cost data in guides or references are often broken down into labor, equipment, and material categories, and may or may not include contractor markups. Costs are typically provided on a national average basis for the year of publication of the reference.
- **Vendor or Contractor Quotes** – Provide costs that are more site-specific in nature than costs taken from standard guides and references. These quotes usually include contractor markups and are typically provided as a total cost rather than categorized as labor, equipment, or materials. If possible, more than one vendor quote should be obtained. Quotes from multiple sources can be averaged, or the highest quote can be used in the cost estimate if the collected quotes seem to be at the low end of the industry range.
- **Experience with Similar Projects** – Engineering judgment should be exercised if cost data from another project need to be adjusted to take into account site- or technology-specific parameters. In addition, sources of actual cost data from government remediation projects are maintained by various federal agencies.

Local Government Planning Tool to Calculate IC/EC Costs for Brownfield Properties


The cost calculator is designed as a voluntary guide for municipal or local governments to assist in calculating their expected costs of implementing and conducting LTS of ICs and ECs at brownfield properties. In general, primary responsibility for maintaining ICs and ECs rests with the property owner and others responsible for cleanup. The state response program often plays a large role in selecting, implementing, and monitoring ICs and ECs; however, local governments, as controllers of local land use and zoning, often have responsibilities associated with ICs and ECs and LTS at brownfield properties. Each of these separate entities may have different roles, responsibilities and costs. It is important to calculate the full cost of LTS for ICs and ECs, both short- and long-term to ensure adequate resources are available for their management over time. Additional information on the institutional and engineering control costs calculating tool can be found in the Local Government Planning Tool to Calculate Institutional and Engineering Control Costs for Brownfield Properties at: www.epa.gov/brownfields/tools/tti_lucs.htm.

- **Cost Estimating Software/Databases/Reports** – The majority of available software tools are designed to estimate the cost for all or selected cost elements of an alternative.
- **Remedial Action Cost Engineering Requirements (RACER)** – A cost estimating system originally developed by the U.S. Air Force. The system uses a patented methodology for generating location-specific program cost estimates. RACER calculates quantities for each technology; localizes unit costs for materials, equipment, and labor; adjusts unit prices for safety and productivity losses; and applies markups to account for indirect costs. It uses current multi-agency pricing data, and is researched and updated annually to ensure accuracy. This software is available for purchase at: www.frtr.gov/ec2/ecracersystem.htm
- **CostPro** – A software program developed by EPA to estimate costs for closure and post-closure plans prepared by Treatment, Storage, and Disposal Facilities (TSDFs) regulated under the Resource Conservation and Recovery Act (RCRA). Under RCRA, owners or operators of interim status and permitted TSDFs must prepare and annually update a cost estimate for closure and post-closure (if applicable) and provide corresponding financial assurance. CostPro uses data from RS Means and ECHOS for specific cost items. EPA limits free distribution of the software only to EPA and state personnel. Others interested in obtaining the software must pay a licensing fee to RS Means and ECHOS that provides the right to use the data incorporated into this software. To obtain further information about CostPro or how to obtain the software: contact Bob Maxey, EPA Headquarters, at (703) 308-7273 or maxey.robert@epa.gov.
- **Micro Computer Aided Cost Engineering System (MCACES)** – A program used by the U.S. Army Corps of Engineers that is linked to the Unit Price Book (UPB) database. www.hnd.usace.army.mil/traces/
- **Federal Remediation Technology Roundtable (FRTR)** – FRTR makes data more widely available on real experiences and lessons learned in selecting and implementing treatment and site characterization technologies to clean up soil and ground water contamination. The remediation case study reports describe the performance and cost of technology applications at full-scale and large-scale demonstration projects. www.frtr.gov/costperf.htm
- **Innovative Treatment Technologies** – Provides information about characterization and treatment technologies for the hazardous waste remediation community. It offers technology selection tools and describes programs, organizations, publications for federal and state personnel, consulting engineers, technology developers and vendors, remediation contractors, researchers, community groups, and individual citizens. www.epa.gov/tio/remed.htm
- **EPA's Cleanup Information (CLU –IN)** – Provides information about innovative treatment technologies and acts as a forum for all waste remediation stakeholders. www.clu-in.org/remediation/
- **A Guide to Developing and Documenting Cost Estimates During Feasibility Study (July 2000)** – This guide provides capital and O&M cost categories and details steps in calculating costs of ECs. www.epa.gov/superfund/policy/remedy/pdfs/finaldoc.pdf
- **Florida Department of Environmental Protection Engineering Controls Report (1999)** – This document considers the adequacy of ECs available for use at contaminated properties; summarizes the types of ECs currently available; evaluates the effectiveness of ECs in protecting human health, and the environment; and evaluates the ability of ECs to achieve risk-based corrective action criteria at contaminated properties. www.dep.state.fl.us/waste/quick_topics/publications/wc/csf/focus/engineer.pdf

For additional information regarding ECs/ICs and LTS, please visit the EPA Brownfields Program at www.epa.gov/brownfields or contact Ann Carroll at (202) 566-2748 or carroll.ann@epa.gov.

Attachment B

Proposed Redevelopment and Underground Detention Area



Attachment C

Updated Lead Exposure Point Concentrations (EPCs)

UCL Statistics for Uncensored Full Data Sets

User Selected Options

Date/Time of Computation ProUCL 5.2 8/22/2023 2:28:26 PM
From File Subsurface Soil Input File.xls
Full Precision OFF
Confidence Coefficient 95%
Number of Bootstrap Operations 2000

Lead_NoOutlier

General Statistics

Total Number of Observations	26	Number of Distinct Observations	26
		Number of Missing Observations	0
Minimum	1.8	Mean	121.7
Maximum	391	Median	75.7
SD	114.5	Std. Error of Mean	22.45
Coefficient of Variation	0.941	Skewness	1.112

Normal GOF Test

Shapiro Wilk Test Statistic 0.853
1% Shapiro Wilk Critical Value 0.891
Lilliefors Test Statistic 0.201
1% Lilliefors Critical Value 0.199

Shapiro Wilk GOF Test

Data Not Normal at 1% Significance Level

Lilliefors GOF Test

Data Not Normal at 1% Significance Level

Data Not Normal at 1% Significance Level

Assuming Normal Distribution

95% Normal UCL

95% Student's-t UCL 160

95% UCLs (Adjusted for Skewness)

95% Adjusted-CLT UCL (Chen-1995) 163.8
95% Modified-t UCL (Johnson-1978) 160.8

Gamma GOF Test

A-D Test Statistic 0.187
5% A-D Critical Value 0.774
K-S Test Statistic 0.0739
5% K-S Critical Value 0.176

Anderson-Darling Gamma GOF Test

Detected data appear Gamma Distributed at 5% Significance Level

Kolmogorov-Smirnov Gamma GOF Test

Detected data appear Gamma Distributed at 5% Significance Level

Detected data appear Gamma Distributed at 5% Significance Level

Gamma Statistics

k hat (MLE)	0.993	k star (bias corrected MLE)	0.904
Theta hat (MLE)	122.5	Theta star (bias corrected MLE)	134.6
nu hat (MLE)	51.62	nu star (bias corrected)	47
MLE Mean (bias corrected)	121.7	MLE Sd (bias corrected)	128
		Approximate Chi Square Value (0.05)	32.27
Adjusted Level of Significance	0.0398	Adjusted Chi Square Value	31.46

Assuming Gamma Distribution

95% Approximate Gamma UCL 177.2

95% Adjusted Gamma UCL 181.7

Lognormal GOF Test

Shapiro Wilk Test Statistic 0.931
10% Shapiro Wilk Critical Value 0.933
Lilliefors Test Statistic 0.14
10% Lilliefors Critical Value 0.156

Shapiro Wilk Lognormal GOF Test

Data Not Lognormal at 10% Significance Level

Lilliefors Lognormal GOF Test

Data appear Lognormal at 10% Significance Level

Data appear Approximate Lognormal at 10% Significance Level

Lognormal Statistics

Minimum of Logged Data	0.588	Mean of logged Data	4.219
Maximum of Logged Data	5.969	SD of logged Data	1.316

Assuming Lognormal Distribution

95% H-UCL 350.2

90% Chebyshev (MVUE) UCL 294.9

95% Chebyshev (MVUE) UCL 359.3
99% Chebyshev (MVUE) UCL 624.6

97.5% Chebyshev (MVUE) UCL 448.8

Nonparametric Distribution Free UCL Statistics
Data appear to follow a Discernible Distribution

Nonparametric Distribution Free UCLs

95% CLT UCL 158.6
95% Standard Bootstrap UCL 157.3
95% Hall's Bootstrap UCL 161
90% Chebyshev(Mean, Sd) UCL 189
97.5% Chebyshev(Mean, Sd) UCL 261.8

95% BCA Bootstrap UCL 160.9
95% Bootstrap-t UCL 165.2
95% Percentile Bootstrap UCL 159.6
95% Chebyshev(Mean, Sd) UCL 219.5
99% Chebyshev(Mean, Sd) UCL 345

Suggested UCL to Use

95% Adjusted Gamma UCL 181.7

Note: Suggestions regarding the selection of a 95% UCL are provided to help the user to select the most appropriate 95% UCL.
Recommendations are based upon data size, data distribution, and skewness using results from simulation studies.
However, simulations results will not cover all Real World data sets; for additional insight the user may want to consult a statistician.